



USE THIS DETAIL IN CONJUNCTION WITH DETAIL CP-72.

**NOTE:**  
 THIS DRAWING INDICATES THE PROCEDURE FOR INSTALLING MasterProtect® ANODES WITH HIGH RESISTIVITY REPAIR MORTARS (GREATER THAN 25,000-OHM-CM). ALL MATERIALS SHOULD BE HANDLED AND APPLIED ACCORDING TO MASTER BUILDERS SOLUTIONS TECHNICAL DATA GUIDES.

CURRENT ISSUE DATE: 1 APR 2021	DRAWN BY: BJS
DATE CREATED: 15 JUN 2010	CHECKED BY: WJG
DRAWING NO: <b>CP-71</b>	

**STANDARD DETAIL**  
**MasterProtect® Anodes**  
**INSTALLATION IN HIGH RESISTIVITY MORTARS**



**Master Builders Solutions Construction Systems US LLC**  
 889 Valley Park Drive  
 Shakopee, MN 55379

**Customer Service:** 800-443-9517  
**Technical Service:** 800-243-6739  
[www.master-builders-solutions.com/en-us](http://www.master-builders-solutions.com/en-us)

A brand of  
**MBC GROUP**

Information provided herein, including but not limited to, any drawing, design, photograph, graphic, or statement(s) ("Materials") are proprietary and the property of Master Builders Solutions Construction Systems US, LLC ("Company"). Reproduction, translation, or reduction to any electronic medium or machine readable form, in whole or part, is strictly prohibited, except for the express purpose for which it has been furnished, without prior written consent of Company. All Materials contained herein are provided by Company for information purposes only. Company reserves the right to amend or withdraw any information contained in the Materials without notice. All technical or other advice by Company, whether verbal or written, concerning products, or the use of products in specific situations ("Advice") is given by Company and is used at the Users own risk.