

THIS METHOD STATEMENT COVERS PREPARATION AND APPLICATION OF **MasterProtect 190SP**.

METHOD STATEMENT: MasterProtect 190SP - Airless Spray Equipment

1. GENERAL:

- 1.1. All areas not to be coated, but which may be affected by spillage or overspray shall be fully masked. Flora and fauna shall be protected.
- 1.2. Any further areas to be coated, shall be at the discretion of the Engineer and subject to re-measurement.
- 1.3. All deviations from the original Bill of Quantities or scope of works must be agreed in writing with the Engineer before application starts.

2. PREPARATION:

- 2.1. All surfaces shall be free from oil, grease, friable matter and general curing compounds (wax based curing membranes shall not be used in areas to be over coated).
- 2.2. Concrete surfaces shall be cleaned using high pressure water jetting, grit blasting, or other methods approved by the Engineer. Surface profile equal to ICRI CSP 1-3 (Max) should be achieved.
- 2.3. Arrises shall be rounded off and surface protrusions shall be ground down to ensure a smooth substrate.
- 2.4. All blow holes and other surface defects shall be made good using **MasterBrace ADH 2200**.

MasterBrace ADH 2200 - Mix Part A with Part B until a uniform, streak free colour is obtained. Full packs only should be mixed.

Part mixing can be carried out as long as the ratio (by weight) of the Parts A & B are accurately maintained.

- 2.5. Application shall be by spatula or flexible scrapper, ensuring blow holes and other minor defects are completely filled.
- 2.6. Allow the applied material to cure for at least 12 hours before sanding down to a smooth finish flush with the concrete surface.
- 2.7. Wipe the prepared surface to remove all dust with a damp clean cloth and allow to dry.

3. TEMPERATURE CONDITION:

- 3.1. **MasterProtect 190SP** shall be used when the ambient temperature is above 10°C.
- 3.2. Substrate temperatures should not be less than 10°C. In hot weather areas, to be coated shall be shaded from direct sunlight to prevent the substrate temperature exceeding 40°C.
- 3.3. Coating shall not be applied if the humidity is likely to rise above RH 85% or the temperature is within 3°C of the dew point before or during the application.

4. MIXING:

- 4.1. The total contents of the reactor component (Part B) shall be poured into the base component (Part A) and mixed, using a slow speed drill with suitable mixing attachment. Mixing time shall not be less than 3 minutes until a uniform colour is achieved.
- 4.2. **NOTE: As the kit size is 13.5 kg, once mixed it is imperative that it is applied immediately.**

Leaving the MasterProtect 190SP as a 13.5 kg mixed kit in its original container will greatly reduce its pot life, it MUST be poured out into the spray equipment's holding tank(s) and be fully discharged within the working time of the product – high ambient temperatures WILL greatly reduce this working time. If necessary, split between 2 spray machines or have 2 spray guns operating from the one machine to speed up the application time.

Partial mixing is NOT recommended but can be done IF accurate weighing scales are available to exactly measure out both components to their correct mixing ratios.

5. APPLICATION:

- 5.1. Application shall be by airless spray gun using the correct nozzle size to provide the required WFT for each coat. This can only be determined by site-based trials as equipment performance varies from one manufacturer to another. **A spray nozzle size of around 19-23 thou is the typical that is required BUT this needs to be confirmed by trials on site.**
- 5.2. The first coat shall be applied giving total coverage of the prepared area, ensuring a **minimum wet film thickness of 200 microns**. Allow to cure for at least 6 hours (must be tack-free). **MasterProtect 190SP being a solvent free material has a wet and dry film thickness that would be the same.**
- 5.3. The coating shall then be inspected for any pinholes or other defects. These shall be made good with **MasterBrace ADH 2200**.
- 5.4. The subsequent coat(s) (**WFT 200 microns minimum**) shall be applied within 16 hours at 40°C or 36 hours at 20°C. If the application of the subsequent coat (s) is delayed the previous coat shall be abraded and wiped with a lint free cloth, dampened with Xylene / MEK / Acetone immediately prior to the application of subsequent coats. Allow solvent wipe to fully dry before continuing with the application of subsequent coats.

6. CLEAN UP:

- 6.1. The mixing equipment, spray line(s) and gun etc. should be thoroughly cleaned using Xylene / MEK / Acetone solvent whilst the material is still fluid. Once hardened it can only be removed by mechanical means.
- 6.2. All contaminated solvent used for cleaning purposes should be either recycled or disposed of in the correct manner.

STATEMENT OF RESPONSIBILITY

The technical information and application advice given in this Master Builders Solutions publication are based on the present state of our best scientific and practical knowledge. As the information herein is of a general nature, no assumption can be made as to a product's suitability for a particular use or application and no warranty as to its accuracy, reliability or completeness either expressed or implied is given other than those required by law. The user is responsible for checking the suitability of products for their intended use.

NOTE

Field service where provided does not constitute supervisory responsibility. Suggestions made by Master Builders Solutions either orally or in writing may be followed, modified or rejected by the owner, engineer or contractor since they, and not Master Builders Solutions, are responsible for carrying out procedures appropriate to a specific application.
