

Procedures for Repairing EIFS

INTRODUCTION

Impact damage can result from various causes such as vandalism, hail or landscaping activities. Impact exceeding the strength of the reinforcing mesh used in EIFS construction can rupture the EIFS surface. EIFS can be designed to have tremendous impact strength. Before repairing punctured EIFS, consideration should be given to the anticipated use conditions. If EIFS are expected to withstand routine impact force, a high-impact surfacing system should be installed. In addition to creating a durable repair, installing an all-new surfacing system may provide an enhanced appearance.

Properly installed EIFS should not crack. When cracking is found, a root cause analysis is needed to determine the cause of cracking, otherwise repairs may not be effective. In some cases, EIFS installation deficiencies can be corrected. Where underlying substrate conditions or structural movement cause cracks to form, a more extensive repair may be needed.

REPAIRING IMPACT DAMAGE

1. Cut around the damaged area with a razor knife, cutting through all layers, to the substrate or the water-resistive barrier (if the system is an EIFS with Drainage). Make sure the patch area is large enough to easily work within, even if the damaged area is small.
2. Carefully remove the EIFS lamina.
3. Remove the damaged EPS. Inspect the water-resistive barrier and repair as necessary if damaged during EIFS removal.
4. A hand-held grinder can be used to remove the finish surrounding the removed section of EIFS. Do not grind into reinforcing mesh; remove finish in a uniform area, at least 3-inches in all directions surrounding the removed portion of EIFS. Alternately, if working in an area where dust control is needed, use of paint remover is recommended. Apply paint remover gel around the puncture and allow it to soften the finish. Use a scraper to remove the finish, and coarse sandpaper to roughen the base coat.
5. Remove all debris (dust, EPS beads, etc.) from cutting and grinding.
6. Cut new EPS to the shape of the EPS void, creating a tightly fitting repair. Apply Finestone A/BC or A/BC 1-Step Base Coat to the new EPS and press it into place. Allow the adhesive

to dry. Insert EPS slivers into any gap greater than 1/16-inch wide. Do not fill gaps between insulation board with base coat. Sand or rasp the surface flush with adjacent EPS.

Note: For mechanically fastened EIFS, small areas of EPS can be friction fit. Larger areas of damage will require stud to stud removal to fasten new EPS.

7. Mask the existing finish around the repair area.
8. Cut Finestone Reinforcing Mesh so that it overlaps at least 1-inch onto existing base coat and mesh. Embed Finestone Reinforcing Mesh into A/BC or A/BC 1-Step Base Coat, ensuring that fresh base coat and mesh is level with the existing lamina. Use a double layer of Finestone when repairing damaged corners. Allow to dry and scrape any trowel marks prior to finish application.
9. Apply color and texture matched Finestone finish. Float the finish to match existing finish. Remove the masking tape before the finish dries and use a brush to blend the wet edge of the finish into existing finish and allow to dry.

REPAIRING CRACKS

1. Identify and mark the extent of cracking so that the entire cracked area is repaired. For aesthetic reasons, resurfacing should be terminated at an architectural break in the wall such as a reveal, change in plane or change in elevation. Doing this minimizes the contrast between resurfaced areas and adjacent finishes.
2. If working in an area where dust control is needed, use of paint remover is recommended. Apply paint remover to the marked area and allow it to soften the finish. Use a scraper to remove the finish, and coarse sandpaper to remove base coat down to the reinforcing mesh. Alternately, a hand-held grinder can be used to remove both finish and base coat. Do not grind into reinforcing mesh. Remove finish and base coat at least 3-inches in all directions surrounding the crack.
3. Assess the root cause of cracking to select the appropriate repair method.
 - If cracking is caused by excessive gap between insulation boards, remove base coat and mesh surrounding the crack. Fill the crack with EPS slivers. Do not fill gaps between insulation board with base coat. Shave or rasp foam flush with the surrounding insulation. Embed Finestone Reinforcing Mesh in Alpha or Alpha Dry Base Coat over the repaired insulation board and extending at least 2.5-inches onto existing base coat and creating a smooth transition from existing base coat to new base coat.
 - If cracking is caused by excessive gap between insulation boards that has been filled with base coat, the base coat must be removed. Cut out surrounding EPS insulation and follow the repairing impact damage procedure.
 - If cracking is caused by mesh that has insufficient or no overlap, embed Finestone Reinforcing Mesh and Alpha or Alpha Dry Base Coat over the affected area and extend at least 2.5-inches onto existing base coat. Create a smooth transition from existing base coat to new base coat.
4. Apply masking tape around the area that has been repaired. Apply color and texture matched Finestone finish. Float the finish to match existing finish. Remove the masking tape and use a brush to blend the wet edge of the finish into existing finish and allow to dry.

AESTHETIC REVEALS

For cracks that occur in aesthetic reveals the following procedure can be used to seal the crack and protect against moisture intrusion:

1. Clean the area around the crack and allow it to dry.
2. Apply bond breaker tape centered over the crack to prevent three-sided adhesion.
3. Install Master Builders Solutions MasterSeal NP100 or NP150 sealant over the bond breaker tape. Tool the sealant in two directions, ensuring a minimum ¼ inch contact to the EIFS surface along each side of the reveal. Allow sealant to dry.

CONSIDERATIONS AND CONDITIONS:

- Realize that repairs may be visible after completion, matches to existing finish texture and color may be difficult.
- Consider recoating or resurfacing the affected panel or elevation if aesthetic repair is needed.
- Consider resurfacing all areas that are subject to impact using Master Builders Solutions Hi-Impact 20 mesh and Finestone Reinforcing Mesh. This will create a strong, durable, and attractive repair. Reference Technical Bulletin *Procedure for Resurfacing EIFS* for further information.
- For any procedures requiring removal to the substrate, advise your design team when application of AWRB is needed.

LIMITED WARRANTY NOTICE: Master Builders Solutions Construction Systems US, LLC ("Master Builders") warrants this product to be free from manufacturing defects and to meet the technical properties on the current Technical Data Guide, if used as directed within shelf life. Satisfactory results depend not only on quality products but also upon many factors beyond our control. Master Builders MAKES NO OTHER WARRANTY OR GUARANTEE, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO ITS PRODUCTS. The sole and exclusive remedy of Purchaser for any claim concerning this product, including but not limited to, claims alleging breach of warranty, negligence, strict liability or otherwise, is shipment to purchaser of product equal to the amount of product that fails to meet this warranty or refund of the original purchase price of product that fails to meet this warranty at the sole option of Master Builders. Any claims concerning this product must be received in writing within one (1) year from the date of shipment and any claims not presented within that period are waived by Purchaser. Master Builders WILL NOT BE RESPONSIBLE FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFITS) OR PUNITIVE DAMAGES OF ANY KIND.

Purchaser must determine the suitability of the products for the intended use and assumes all risks and liabilities in connection therewith. This information and all further technical advice are based on Master Builders present knowledge and experience. However, Master Builders assumes no liability for providing such information and advice including the extent to which such information and advice may relate to existing third-party intellectual property rights, especially patent rights, nor shall any legal relationship be created by or arise from the provision of such information and advice. Master Builders reserves the right to make any changes according to technological progress or further developments. The Purchaser of the Product(s) must test the product(s) for suitability for the intended application and purpose before proceeding with a full application of the product(s). Performance of the product described herein should be verified by testing and carried out by qualified experts.

For the most current version of this literature, please visit our website at finestone.master-builders-solutions.com/en.

Master Builders Solutions
Construction Systems US, LLC

889 Valley Park Drive, Shakopee MN 55379
finestone.master-builders-solutions.com/en

Customer Service +1 (800) 433-9517
Technical Service +1 (800) 589-1336

© MBCC Group, rev 01.10.2023

® registered trademark of a MBCC Group member in many countries of the world