

THIS METHOD STATEMENT COVERS PREPARATION AND APPLICATION OF **MasterSeal AWB 661HP** ON VARIOUS FRAMING AND SHEATHING/CARRIER BOARDS.

METHOD STATEMENT: MasterSeal AWB 661HP

1. SURFACE PREPARATION:

- 1.1. The prepared surface must be dry, clean, sound and free of release agents, paint or other residual coatings.
- 1.2. Verify the substrate is flat, free of fins or planar irregularities greater than 6.4mm in 3m
- 1.3. Any unsatisfactory conditions should be reported to the main contractor and corrected before application of the **MasterSeal AWB 661HP**.
- 1.4. Substrate shall be of a type acceptable by Master Builder Solutions and installed as per substrate manufacturer's instructions and local building code requirements.

2. MIXING:

- 2.1. Mix **MasterSeal AWB 661HP** with a clean rust-free paddle and drill until thoroughly blended. Dilution of **MasterSeal AWB 661HP** is not recommended.

3. APPLICATION:

- 3.1. A 20 mm (3/4) nap roller or stainless steel trowel is recommended to apply **MasterSeal AWB 661HP**.
- 3.2. Prewet new roller pads and spin out excess water, this should be done once only to ensure the new roller pads fully saturate with the **MasterSeal AWB 661HP**.
- 3.3. Apply the **MasterSeal AWB 661HP** to all sheathing/carrier board joints.
- 3.4. Immediately install sheathing fabric and center over wet **MasterSeal AWB 661HP** and complete saturate sheathing fabric with **MasterSeal AWB 661HP**.
- 3.5. Allow the **MasterSeal AWB 661HP** and sheathing fabric to dry to the touch
- 3.6. Apply **MasterSeal AWB 661HP** to the entire sheathing/carrier board substrate at a minimum wet film thickness of 250 microns.
- 3.7. Always ensure the roller is fully loaded to ensure an even application thickness of **MasterSeal AWB 661HP**.
- 3.8. Once the **MasterSeal AWB 661HP** has cured, typically 2 to 4 hours visually inspect to ensure that the surface is blister free and coating is free of voids and pin holes. Carry out repairs if needed by applying additional **MasterSeal AWB 661HP** such that the **MasterSeal AWB 661HP** is free of voids Pinholes etc.

NOTE: Temperature, humidity, wind and substrate moisture can all affect curing time.

STATEMENT OF RESPONSIBILITY

The technical information and application advice given in this Master Builders Solutions publication are based on the present state of our best scientific and practical knowledge. As the information herein is of a general nature, no assumption can be made as to a product's suitability for a particular use or application and no warranty as to its accuracy, reliability or completeness either expressed or implied is given other than those required by law. The user is responsible for checking the suitability of products for their intended use.

NOTE

Field service where provided does not constitute supervisory responsibility. Suggestions made by Master Builders Solutions either orally or in writing may be followed, modified or rejected by the owner, engineer or contractor since they, and not Master Builders Solutions, are responsible for carrying out procedures appropriate to a specific application.
